




REMOVAL PROCEDURE



S E R V I C E M A N U A L

3.5 kW Class

-  Outdoor Unit
-  Non-Inverter
-  Pair Type



Service Manual Removal Procedure

Outdoor Unit

●Cooling Only

RNE35LV1

RNE35MV1

RNE35MV14

RNE35MV1V9

Table of Contents

1. Outer Panels	2
2. Outdoor Fan / Fan Motor.....	4
3. Electrical Components / Partition Plate.....	6
4. Sound Blanket.....	9
5. Capillary Tube	10
6. Compressor.....	12



Note: ♦ The illustrations may be slightly different depending on the model.





1. Outer Panels





Warning

◆ Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the screw of the stop valve cover.	
2	Slide the stop valve cover downward and remove it.	
3	Remove the 3 screws and remove the top panel.	<ul style="list-style-type: none"> ■ The stop valve cover is united with the shield plate. ■ When reassembling, make sure to fit the 3 hooks.
4	Remove the 6 screws of the front panel.	



Step	Procedure	Points
5	Unfasten the 2 left side hooks, and then the 2 right side hooks.	
6	Remove the front panel.	
7	Press the 2 projections from the rear side and rotate the discharge grille to the left to unfasten the 6 hooks.	
8	Remove the discharge grille.	















2. Outdoor Fan / Fan Motor



Warning

◆ Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Procedure	Points
1	Remove the nut and remove the outdoor fan.		<p>■ Nut size: M6</p>  <p>■ Align the ▼ mark of the outdoor fan with the D-cut section of the motor shaft when reassembling.</p>
2	Pull out the terminal (front-black) from the terminal board X1M (1).		<p>■ When reassembling, put the fan motor lead wire through the back of the fan motor so as not to be entangled with the outdoor fan.</p> 
3	Pull out the 2 terminals (red, white) from the capacitor (C1R).		<p>Terminal board</p> 
4	Cut the clamp and release the fan motor lead wire from the groove.		<p>Capacitor</p> 

Step	Procedure	Points
5	Remove the screw and remove the fan motor fixing frame.	<ul style="list-style-type: none"> ■ When reassembling, fit the 2 lower hooks into the bottom frame.
6	Unfasten the 2 hooks on the fan motor fixing frame and release the fan motor lead wire.	 <p>(R10460)</p>
7	Remove the 3 screws and remove the fan motor.	<ul style="list-style-type: none"> ■ M4 x 12
	 <p>Fan motor fixing frame</p> <p>(R21350)</p>  <p>Fan motor lead wire</p> <p>Hook</p> <p>(R21351)</p>  <p>Fan motor</p> <p>(R21352)</p>	




3. Electrical Components / Partition Plate







Warning




◆ Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the screw of the wire fixture.	
2	Unfasten the hook and remove the wire fixture.	
3	Remove the 2 screws on the terminal board and disconnect the connecting wire.	
4	Remove the 5 screws and remove the right side panel.	



Step	Procedure	Points
5	Slide the right side panel upward to unfasten the 2 hooks.	<ul style="list-style-type: none"> When reassembling, make sure to fit the rear hook.
6	Remove the right side panel.	
7	Pull out the 2 terminals (back-blue, back-black) from the terminal board (X1M).	
8	Pull out the 3 terminals (yellow, red, black) from the capacitor (C1R).	 <p data-bbox="488 1760 1066 1783">* When reassembling, confirm the terminal location.</p>
		

Step	Procedure	Points
9	Loosen the 2 screws of the capacitor fixing band.	
10	Remove the capacitor.	
11	Remove the 2 screws and lift up the partition plate to remove it.	<ul style="list-style-type: none"> ■ When reassembling, fit the partition plate to the hook at the bottom frame.





4. Sound Blanket



Warning

- ◆ Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<p>1 Untie the 2 strings and pull out the sound blanket.</p>	 <p style="text-align: center;">Sound blanket (R21364)</p>  <p style="text-align: center;">(R21365)</p>	<ul style="list-style-type: none"> ■ Since the piping ports on the sound blanket are torn easily, remove the blanket carefully.

5. Capillary Tube



Warning

- ◆ Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.
- ◆ Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas brazing machine.
- ◆ If the refrigerant gas leaks during work, ventilate the room. (If the refrigerant gas is exposed to flames, toxic gas may be generated.)



Caution




- ◆ From the viewpoint of global environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to collect all the refrigerant gas.
- ◆ Restore the piping by non-oxidation brazing.



Note

- ◆ Before working, make sure that the refrigerant gas is empty in the circuit.
- ◆ Be sure to apply nitrogen replacement when heating up the brazed part.
- ◆ Do not use a metal saw for cutting pipes by all means because the sawdust comes into the circuit.
- ◆ When withdrawing the pipes, be careful not to pinch them firmly with pliers. The pipes may get deformed.
- ◆ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.
- ◆ Be careful so as not to burn the compressor terminals, the name plate, the outdoor heat exchanger fin.
- ◆ In case of difficulty with gas brazing machine
 1. Disconnect the brazed part where is easy to disconnect and restore.
 2. Cut pipes on the main unit with a tube cutter in order to make it easy to disconnect.

Step	Procedure	Points
<p>1 Remove the nut together with the rubber washer then remove the terminal cover.</p>		

Step	Procedure	Points
2	Disconnect the compressor lead wires and remove the gasket.	 <p>(R21367)</p>
3	Remove the sheets of putty.	<p>■ Capillary tube</p>
4	Heat up the 2 brazed parts and remove the capillary tube.	 <p>(R21368)</p>
		 <p>(R21469)</p>

6. Compressor



Warning

- ◆ Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.
- ◆ Be careful not to get yourself burnt with the pipes and other parts that are heated by the gas brazing machine.
- ◆ If the refrigerant gas leaks during work, ventilate the room. (If the refrigerant gas is exposed to flames, toxic gas may be generated.)
- ◆ Since it may happen that the refrigerant oil in the compressor catches fire, prepare wet cloth so as to extinguish fire immediately.




Caution




- ◆ From the viewpoint of global environment protection, do not discharge the refrigerant gas in the atmosphere. Make sure to collect all the refrigerant gas.
- ◆ Restore the piping by non-oxidation brazing.



Note

- ◆ Before working, make sure that the refrigerant gas is empty in the circuit.
- ◆ Be sure to apply nitrogen replacement when heating up the brazed part.
- ◆ Do not use a metal saw for cutting pipes by all means because the sawdust comes into the circuit.
- ◆ When withdrawing the pipes, be careful not to pinch them firmly with pliers. The pipes may get deformed.
- ◆ Provide a protective sheet or a steel plate so that the brazing flame cannot influence peripheries.
- ◆ Be careful so as not to burn the compressor terminals, the name plate, the outdoor heat exchanger fin.
- ◆ In case of difficulty with gas brazing machine
 1. Disconnect the brazed part where is easy to disconnect and restore.
 2. Cut pipes on the main unit with a tube cutter in order to make it easy to disconnect.

Step	Procedure	Points
1 Remove the nut together with the rubber washer then remove the terminal cover.		

Step	Procedure	Points
2	Disconnect the compressor lead wires and remove the gasket.	 <p>(R21367)</p>
3	Remove all sheets of the putty.	 <p>(R21369)</p>
4	Heat up the brazed part of the discharge side pipe and disconnect it.	 <p>(R21370)</p>
5	Heat up the brazed part of the suction side pipe and disconnect it.	
6	Remove the 3 nuts of the compressor.	
7	Lift the compressor up and remove it.	

Revision History

Month / Year	Version	Revised contents
03 / 2015	Si011414E	First edition

Warning



- Daikin products are manufactured for export to numerous countries throughout the world. Prior to purchase, please confirm with your local authorised importer, distributor and/or retailer whether this product conforms to the applicable standards, and is suitable for use, in the region where the product will be used. This statement does not purport to exclude, restrict or modify the application of any local legislation.
- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorised parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the user's manual carefully before using this product. The user's manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any enquiries, please contact your local importer, distributor and/or retailer.

Cautions on product corrosion

1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.

Dealer

DAIKIN INDUSTRIES, LTD.

Head Office:
Umeda Center Bldg., 2-4-12, Nakazaki-Nishi,
Kita-ku, Osaka, 530-8323 Japan

Tokyo Office:
JR Shinagawa East Bldg., 2-18-1, Konan,
Minato-ku, Tokyo, 108-0075 Japan

<http://www.daikin.com/products/ac/>

©All rights reserved