




REMOVAL PROCEDURE



S E R V I C E M A N U A L

2.0/2.5 kW Class

-  Indoor Unit
-  Inverter
-  Wall Mounted Type



Service Manual Removal Procedure

Indoor Unit

Applicable Models

●Heat Pump

FTXS20K2V1B

FTXS25K2V1B

Table of Contents

1. Removal of Air Filters	2
2. Removal of Horizontal Blade.....	4
3. Removal of Front Panel	6
4. Removal of Front Grille	7
5. Removal of Vertical Blade ASSYs	8
6. Removal of Electrical Box	10
7. Removal of Swing Motor / PCBs.....	13
8. Removal of Indoor Heat Exchanger	18
9. Removal of Fan Rotor / Fan Motor.....	21
10. Exchange of Piping Direction (Drain Hose).....	24



Note: ♦ The illustrations may be slightly different depending on the model.



1. Removal of Air Filters





Procedure



Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<p>1. Appearance features</p>		<p>Warning Dangerous: High voltage A high voltage is applied to all the electric circuits of this product including thermistors.</p> <ul style="list-style-type: none"> ■ When a signal from the remote controller is received, the receiving tone sounds and the operation lamp flickers immediately to confirm the signal reception. ■ When the [ON/OFF] button is kept pressed for 5 seconds, the forced cooling operation is performed for about 15 minutes.
<p>2. Remove the air filters.</p> <p>1 Open the front panel to the position where it stops.</p> <p>2 Slightly push up the center of the air filter to unfasten the 2 hooks.</p>		<ul style="list-style-type: none"> ■ The air filter is not marked for difference between the right and left sides. ■ The air filter can be set easily by inserting it along the guides. ■ Insert the air filter with the "FRONT" mark faced up. ■ Be sure to insert the hooks (at 2 lower positions) when mounting the air filter.

Step	Procedure	Points
3	<p>Pull out the air filter downward and remove it.</p>  <p>(R16658)</p>	
3.	<p>Remove the Titanium apatite photocatalytic air-purifying filters.</p>	
1	<p>The Titanium apatite photocatalytic air-purifying filter is attached to the back of the air filter.</p>  <p>Titanium apatite photocatalytic air-purifying filter</p> <p>Air filter</p> <p>(R8025)</p>	
2	<p>Remove the Titanium apatite photocatalytic air-purifying filter frame by bending the air filter and unfastening the projections from the air filter frame.</p>  <p>Projection</p> <p>(R14599)</p>	
3	<p>Remove the Titanium apatite photocatalytic air-purifying filter from its frame (at 5 positions) by bending it.</p>  <p>Hook</p> <p>(R8027)</p>	<ul style="list-style-type: none"> ■ To prevent the damage, do not remove the Titanium apatite photocatalytic air-purifying filter from the frame when cleaning it. ■ The Titanium apatite photocatalytic air-purifying filter is not marked for difference between the right and left sides.

2. Removal of Horizontal Blade


Procedure



Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points	
1	Open the horizontal blade.	<p>(R16659)</p>	
2	Unfasten the center shaft while bending the horizontal blade slightly.	<p>(R16660)</p> <p>(R16661)</p>	<p>■ The center shaft can be released easily by bending the blade.</p> <p>Cautions for reassembling</p> <ol style="list-style-type: none"> 1. Since the key pattern hook is provided, rotate the horizontal blade and fit it to the right shaft first. 2. Fit the horizontal blade to the center and left shafts.
3	Unfasten the left shaft of the horizontal blade.	<p>(R16662)</p>	
4	Unfasten the right shaft of the horizontal blade.	<p>(R16662)</p> <p>(R16662)</p>	

Step	Procedure	Points
5	<p data-bbox="204 219 464 275">Remove the horizontal blade.</p>  <p data-bbox="999 651 1070 674">(R16663)</p>	

3. Removal of Front Panel

Procedure



Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points	
1	Open the front panel over the position where it stops.	<p>(R16664)</p>	
2	Release the right rotary shaft.	<p>(R16665)</p>	<ul style="list-style-type: none"> ■ The rotary shaft on each side can be released easily by sliding each shaft inward.
3	Release the left rotary shaft.	<p>(R16666)</p>	
4	Remove the front panel.	<p>(R16667)</p>	<ul style="list-style-type: none"> ■ When reassembling the front panel, fit the right and left rotary shafts one by one into the grooves and fully push them in position.






4. Removal of Front Grille

Procedure



Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Remove the 2 screws, which fix the front grille to the main body.  <p style="text-align: right;">(R16668)</p>	
2	The front grille has 3 hooks on the upper part.  <p style="text-align: right;">(R16669)</p>	<ul style="list-style-type: none"> Refer to the removal procedure in a reverse way when reassembling.
3	Press each hook, and also lift the grille up to unfasten the hooks.  <p style="text-align: right;">(R16670)</p>	
4	Pull the upper part of the front grille out and lift the lower part up, and then remove the front grille.  <p style="text-align: right;">(R16671)</p>	<ul style="list-style-type: none"> The convex marks (...) on the front panel indicate the position of the hooks.  <p style="text-align: right;">(R12715)</p> When reassembling, make sure that all the 3 hooks are fastened as they were.


5. Removal of Vertical Blade ASSYs





Procedure





Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1	Unfasten the right and left hooks of the fan guard with pliers.	<ul style="list-style-type: none"> ■ Narrow the edges of the hook to unfasten it.  <p style="text-align: right;">(R11646)</p>
2	Unfasten the 4 hooks at the bottom. Remove the fan guard.	<ul style="list-style-type: none"> ■ Repeat the same procedure to remove the fan guard on the other side.
3	Unfasten the hooks at the upper 2 positions.	<ul style="list-style-type: none"> ■ A vertical blade ASSY has 6 fins. It is impossible to replace only one fin. ■ The vertical blade ASSY is not marked for difference between right and left.



Step	Procedure	Points
4	<p data-bbox="204 215 472 338">Unfasten the 3 hooks at the shaft mounting part by pressing them with a flat screwdriver.</p>  <p data-bbox="986 667 1043 685">(R8022)</p>	
5	<p data-bbox="204 703 432 763">Remove the vertical blade ASSY.</p>  <p data-bbox="986 1081 1043 1099">(R8023)</p>	<ul style="list-style-type: none"> <li data-bbox="1098 703 1455 801">■ Repeat the same procedure to remove the vertical blade ASSY on the other side.

6. Removal of Electrical Box





Procedure



Warning


Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.





Step	Procedure	Points
1. Disconnect the connecting wires.	<p style="text-align: center;">Service cover</p> <p style="text-align: right;">(R16672)</p>	<p>Preparation</p> <ul style="list-style-type: none"> Remove the front grille according to the "Removal of Front Grille".
2. Pull out the service cover down in the direction of the arrow.	<p style="text-align: right;">(R16673)</p>	
3. The figure shows the connections of wire harnesses.	<p style="text-align: center;">Terminal board Electrical box</p> <p style="text-align: center;">Indoor heat exchanger thermistor</p> <p style="text-align: center;">Wire retaining plate</p> <p style="text-align: right;">(R14586)</p>	


Step	Procedure	Points
4	Remove the screw of the wire retaining plate.	 <p>(R12044)</p>
5	Remove the screws of the terminal board and disconnect the connecting wires.	<p>Terminal board</p>  <p>Connecting wires</p> <p>(R11639)</p>
6	Pull out the indoor heat exchanger thermistor.	<p>Indoor heat exchanger thermistor</p>  <p>(R12045)</p>
2. Remove the electrical box.	1 Remove the screw and release the earth wire.	 <p>Screw</p> <p>Earth wire</p> <p>(R17472)</p>

- Connecting wires
- (1): black
- (2): white
- (3): red
- (⊥): yellow / green

- Take care not to lose the clip of thermistor.



Step	Procedure	Points
2	<p>Disconnect the connector for the fan motor [S200]. Release the fan motor harnesses from the hook.</p>	 <p>[S200]</p> <p>(R15844)</p>
3	<p>Remove the screw of the electrical box.</p>	 <p>(R12048)</p>
4	<p>Slide the electrical box to the right first and detach the horizontal blade from the electrical box.</p>	 <p>(R15845)</p>
5	<p>Pull the electrical box.</p>	 <p>Bottom frame</p> <p>Hook</p> <p>(R11657)</p>



■ There is a hook on the bottom frame. When reassembling, fit the rear side of the electrical box to the hook.




7. Removal of Swing Motor / PCBs






Procedure









Warning



Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the shield plate (2).	<p data-bbox="199 450 472 539">1 Unfasten the hooks at the upper 2 positions of the shield plate (2).</p>  <p data-bbox="199 936 472 1061">2 Unfasten the hook at the lower position, and remove the shield plate (2).</p> 	<p data-bbox="1093 376 1241 405">Preparation</p> <ul data-bbox="1093 412 1437 501" style="list-style-type: none"> ■ Remove the electrical box according to the "Removal of Electrical Box".
2. Remove the swing motor.	<p data-bbox="199 1487 472 1547">1 Remove the screw of the swing motor.</p> 	

Step	Procedure	Points
2	<p>Unfasten the hook, and disconnect the connector.</p>  <p>(R8037)</p>	<p>■ The connector of the swing motor has a hook. Press the hook with a flat screwdriver to unfasten it.</p>  <p>(R14847)</p>
3. Remove the PCBs.		
1	<p>Unfasten the hook, and release the display PCB ASSY.</p>  <p>(R16674)</p>	
2	<p>Remove the INTELLIGENT EYE fixing plate by twisting it.</p>  <p>(R16675)</p>	
3	<p>Unfasten the 3 hooks and remove the INTELLIGENT EYE sensor PCB.</p>  <p>(R16652)</p>	

Step	Procedure	Points
4	<p>Disconnect the connector [S36] from the INTELLIGENT EYE sensor PCB.</p>  <p>(R16676)</p>	
5	<p>Turn over the display PCB ASSY, and unfasten the 3 hooks to remove the display PCB.</p>  <p>(R16651)</p>	
6	<p>Disconnect the connector [S27] from the display PCB.</p>	
7	<p>The figure shows the component parts of the display PCB.</p>  <p>(R14848)</p>	<p>[S27]: for control PCB</p>

Step	Procedure	Points
4. Remove the control PCB.		
1	Lift the shield plate (1) and unfasten the 2 hooks.	
2	Slide the shield plate (1) and remove it.	
3	Release the harnesses from the hooks.	
4	Disconnect the terminals from the terminal board with pliers.	<p>1 : black, upper 2 : white, lower 3 : red, upper ≡ : green/yellow, upper ≡ : green, lower</p>
	 <p>(R12061)</p>  <p>(R12062)</p>  <p>(R14609)</p>	

Step	Procedure	Points
5	<p>Release the 4 hooks. Lift up the upper part of the control PCB and remove it.</p>  <p style="text-align: right;">(R16677)</p>	
6	<p>The figure shows the control PCB.</p>  <p style="text-align: right;">(R16653)</p>	<p>[S6]: swing motor [S25]: INTELLIGENT EYE sensor PCB [S26]: display PCB [S32]: indoor heat exchanger thermistor [S200]: fan motor</p>

8. Removal of Indoor Heat Exchanger





Procedure








Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Disconnect the refrigerant piping.	<p>(R12174)</p>	<p>Preparation</p> <ul style="list-style-type: none"> Remove the electrical box according to the "Removal of Electrical Box".
1 Remove the screws which fix the indoor unit to the installation plate.	<p>Wooden base</p> <p>(R12175)</p>	<p>Caution</p> <p>Be sure to stop the compressor before disconnecting the refrigerant pipe. If the refrigerant pipe is disconnected with the compressor running and the stop valve opened, air may be sucked in to generate an over-pressure in refrigeration cycle, thus resulting in pipe rupture or accidental injury.</p>
2 Lift the indoor unit with a wooden base.	<p>Drain hose</p> <p>Extension drain hose</p> <p>Connecting wires</p> <p>(R12176)</p>	<ul style="list-style-type: none"> If the drain hose is embedded in the wall, disconnect the drain hose beforehand. Place a plastic sheet under the drain hose as remaining drain may leak.
3 Pull out the drain hose.	<p>(R12177)</p>	<ul style="list-style-type: none"> Carry out the removal work with 2 wrenches. <p>Caution</p> <p>From the viewpoint of global environmental protection, make sure to use a vacuum pump for air purging.</p> <ul style="list-style-type: none"> When the pipings are disconnected, protect the both openings from entering moisture.
4 Disconnect the flare nut for gas piping.		

Step	Procedure	Points
5	<p>Disconnect the flare nut for liquid piping.</p>  <p>(R12178)</p>	
2	<p>Remove the indoor heat exchanger.</p> <p>1 Remove the indoor unit from the installation plate.</p>  <p>(R12179)</p> <p>2 Unfasten the hook of the piping fixture on the back of the indoor unit.</p>  <p>(R8038)</p>  <p>(R8039)</p>	

Step	Procedure	Points
3	<p>Slightly widen the auxiliary piping.</p>  <p>Auxiliary piping</p> <p>(R8040)</p>	
4	<p>Remove the screw on the left side and unfasten the hook on the rear side.</p>  <p>Hook</p> <p>Screw</p> <p>(R11269)</p>  <p>Hook</p> <p>(R8041)</p>	<p>Caution When removing or reassembling the indoor heat exchanger, be sure to wear gloves or wrap it with cloth before proceeding to the work. (You may be injured by the fins.)</p>
5	<p>Push and unfasten the hook on the right side and lift up the indoor heat exchanger.</p>  <p>Hook</p> <p>(R8042)</p>	
6	<p>Pull the indoor heat exchanger to the front side to unfasten the hooks completely, and then remove it.</p>  <p>Indoor heat exchanger</p> <p>(R8043)</p>	




9. Removal of Fan Rotor / Fan Motor





Procedure






Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
1. Remove the right side panel.	 <p>Right side panel (R8044)</p>	Preparation <ul style="list-style-type: none"> Remove the indoor heat exchanger according to the "Removal of Indoor Heat Exchanger".
1 Remove the screw of the right side panel.	 <p>Hook (R8045)</p>	
2 Unfasten the hook of the right side panel.	 <p>(R8046)</p>	
3 Remove the right side panel.		

Step	Procedure	Points
2.	Remove the fan rotor and the fan motor.	
1	<p>The fan motor has 3 projections on the right side. The fan rotor has a rotating shaft on the left side.</p>  <p>(R8047)</p>	
2	Remove the fan rotor.	
3	Press the bearing from outside.	
4	Remove the bearing.	
	 <p>(R8048)</p>  <p>(R8049)</p>  <p>(R8050)</p>	

Step	Procedure	Procedure	Points
5	Unfasten the 2 hooks of the motor cover.	 <p>(R8051)</p>	
6	Pull out the fan motor from the fan rotor to remove.	 <p>(R8052)</p>  <p>(R8053)</p>	<ul style="list-style-type: none"> ■ The magnet of the fan motor is united with the fan rotor. Be careful not to attract metal waste to the magnet. Keep away from the materials that can be affected by magnetic force also.






10.Exchange of Piping Direction (Drain Hose)

Procedure



Warning

Be sure to wait for 10 minutes or more after turning off all power supplies before disassembling work.

Step	Procedure	Points
<p>1 Remove the heat insulation fixing screw on the right side and remove the drain hose.</p>	 <p>Drain hose</p> <p>Heat insulation fixing screw</p> <p>(R8054)</p>  <p>(R8055)</p>	
<p>2 Remove the drain plug located at the left side with pliers and insert the removed drain plug into the right side with a hexagonal wrench (4 mm).</p>	 <p>Drain plug</p> <p>(R8056)</p>	
<p>3 Insert the drain hose to the left side, and tighten it with the heat insulation fixing screw.</p>	 <p>Drain piping (left)</p> <p>(R8057)</p>	<p> Caution Do not thrust in the drain plug with a sharp-pointed tool like a screwdriver. (The drain plug may be broken, resulting in water leakage.)</p> <ul style="list-style-type: none"> ■ After removing the drain hose, to prevent water leakage, make sure to mount the heat insulation fixing screw as it was.

Revision History

Month / Year	Version	Revised contents
08/2012	Si041140	First edition

Warning



- Daikin products are manufactured for export to numerous countries throughout the world. Prior to purchase, please confirm with your local authorised importer, distributor and/or retailer whether this product conforms to the applicable standards, and is suitable for use, in the region where the product will be used. This statement does not purport to exclude, restrict or modify the application of any local legislation.
- Ask a qualified installer or contractor to install this product. Do not try to install the product yourself. Improper installation can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Use only those parts and accessories supplied or specified by Daikin. Ask a qualified installer or contractor to install those parts and accessories. Use of unauthorised parts and accessories or improper installation of parts and accessories can result in water or refrigerant leakage, electrical shock, fire or explosion.
- Read the User's Manual carefully before using this product. The User's Manual provides important safety instructions and warnings. Be sure to follow these instructions and warnings.

If you have any enquiries, please contact your local importer, distributor and/or retailer.

Cautions on product corrosion

1. Air conditioners should not be installed in areas where corrosive gases, such as acid gas or alkaline gas, are produced.
2. If the outdoor unit is to be installed close to the sea shore, direct exposure to the sea breeze should be avoided. If you need to install the outdoor unit close to the sea shore, contact your local distributor.

Dealer

DAIKIN INDUSTRIES, LTD.

Head Office:
Umeda Center Bldg., 2-4-12, Nakazaki-Nishi,
Kita-ku, Osaka, 530-8323 Japan

Tokyo Office:
JR Shinagawa East Bldg., 2-18-1, Konan,
Minato-ku, Tokyo, 108-0075 Japan

http://www.daikin.com/global_ac/

©All rights reserved